

Cod. **LPLAFO604**: KIT PLAFONIERA x LP6060 ALUMINUM FRAME 598X598X80mm  
 Cod. **LPLAFO301204**: KIT PLAFONIERA x LP30120 ALUMINUM FRAME 298X1198X80mm  
 Cod. **LPLAFO601204**: KIT PLAFONIERA x LP60120 ALUMINUM FRAME 598X1198X80MMmm



1200x600x80mm



1200x300x80mm



600x600x80mm

### Fasi di montaggio - Installation steps

- Phases d'assemblage - Montaje - Postopek montaže

- I:**
- 1- Assemblare 3 lati utilizzando le viti fornite.
  - 2- Fissare la cornice al soffitto con viti e tasselli forniti.
  - 3- Inserire il pannello collegandolo elettricamente.
  - 4- Chiudere la cornice.

Disponibile per pannelli 595x595mm - 295x1195mm. - 595x1195mm

- GB:**
- 1- Assemble 3 sides of the frame using the supplied screws.
  - 2- Fix the frame to the ceiling using the supplied screws and dowels.
  - 3- Insert the panel Connecting the panel electrically and insert it into the frame.
  - 4- Close the last side of the frame securing it with the screws.

Screw the frame on the ceiling. Fixing the panel in the frame.

Available for 595x595mm - 295x1195mm. - 595x1195mm panels.

- FR:**
- 1- Assembler 3 côtés en utilisant les vis fournies.
  - 2- Fixer le châssis au plafond avec les vis et les chevilles fournies.
  - 3- Insérer la dalle en la connectant électriquement.
  - 4- Fermer la châssis.

Disponible pour les dalles 595x595mm - 295x1195mm. - 595x1195mm

- ES:**
- 1- Ensamble los 3 lados con los tornillos suministrados.
  - 2- Fije el marco al techo con los tornillos y tapones suministrados.
  - 3- Inserte el panel conectándolo eléctricamente.
  - 4- Cerrar el marco.

Disponibile para paneles de 595x595mm - 295x1195mm. - 595x1195mm

- SL:**
- 1- Povezati tri stranice s priloženimi vijaki.
  - 2- Privijačiti ohišje na primarni strop s priloženimi vijaki in vložki.
  - 3- Vstaviti panel in ga priključiti na napajanje.
  - 4- Dodati manjkajočo stranico.

Na voljo za panele dimenzij 595x595mm - 295x1195mm. - 595x1195mm.

