



# DISC SLIM


REF: K51700.SR



## INSTALLATION INSTRUCTIONS



V.01



^K51700.01	^K51700.02	^K51700.03	□K51700.04	*K51700.05	□K51700.06	*K51700.07
<p><b>1</b> </p> <p><b>2</b> </p> <p><b>3</b> </p> <p><b>4 CONNECTION</b></p> <p></p> <p>                     ON-OFF: L, N, SEC+, SEC-                      PUSH1: L, N, PUSH, SEC+, SEC-                      DALI: L, N, DA1, DA2, SEC-                      1-10V: L, N, 1-10V, SEC+, SEC-                      PUSH2: L, N, PUSH, DA/N, DA/L, SEC+, SEC-                      PHASE CUT: DIMMER, L, N, SEC+, SEC-                 </p> <p>*Models 05 and 07 don't work with PHASE CUT                      ^Models 01, 02 and 03 works with DIMMABLE REMOTE DRIVER                      □Model 04 and 06 works with PC REMOTE DRIVER</p> <p><b>5</b> </p> <p><b>6</b> </p> <p><b>7</b> </p>						