

INSTALLATION MANUAL


67396A

ecolight



80
CRI

230V | SMD 2835 | 6W | IP65 | Sensor | ABS + PC



one
LIGHT



<p>A</p>	<p>B</p>																				
<p>C</p>	<p>D Sensitivity Configuration and Time delay</p> <p>ON</p> <table border="1"><tr><td></td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>*SENSITIVITY</td><td>5sec</td><td>30sec</td><td>1min</td><td>3min</td><td>5min</td><td>8min</td></tr><tr><td></td><td colspan="5">Time Delay</td><td></td></tr></table> <p>* OFF High sensitivity ON Low sensitivity Move switch to ON position to adjust time delay.</p>							*SENSITIVITY	5sec	30sec	1min	3min	5min	8min		Time Delay					
*SENSITIVITY	5sec	30sec	1min	3min	5min	8min															
	Time Delay																				
<p>E</p>	<p>F</p>																				

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.