












IP66










220-240V  
50/60Hz



IP66

220-240V  
50/60Hz



Installation can only be carried out by an authorized person and according to the mounting instructions. Any other installation is considered to be improper. For well installation and good luminaire work is necessary ensure a planarity of a mounting surface. Make sure that the luminaire is always disconnected from the power supply before the installation work. Do not use the luminaire if damaged or if damaged the power cable. Only damp microfiber cloth can be used for cleaning. technical changes are subjected without notice. Do not dispose the luminaire or its parts as household waste, but make the proper recycling.

Table of maximal number of luminaires in one line				10A B	10A C	16A B	16A C
				Σ luminaires	Σ luminaires	Σ luminaires	Σ luminaires
Length	Σlm	Σlm	Σlm				
2.4ft	5200	6400	8800	10	16	16	26
2.5ft	6500	8000	11000	10	16	16	26

Table of maximal number of luminaires in one line				10A B	10A C	16A B	16A C
				Σ luminaires	Σ luminaires	Σ luminaires	Σ luminaires
Length	Σlm	Σlm	Σlm				
2.4ft	5200	6400	8800	11	18	18	30
2.5ft	6500	8000	11000	11	18	18	30



The light source in this luminaire may be replaced only by the manufacturer or its contractual service technician or similarly qualified person!

